

Operating Instructions

Features

- ◆ In and out dual-way temperature measuring
- ◆ Function of clock display

Parameters

- ◆ Temperature range: $50^{\circ}\text{C} \sim +70^{\circ}\text{C}$
- ◆ Accuracy: $\pm^{\circ}\text{C}$
- ◆ Resolution : higher than -20°C , 0.1°C ;
no more than -20°C , 1°C
- ◆ power: 1.5v one LR44

Operating Instructions

Switch between in and outside temperature measuring

- ◆ When electrified for 2 seconds to measure inside temperature and the LCD will display IN
- ◆ Press key [FSW] to switch into outside temperature measuring and the LCD will display OUT.

Clock function setting

- ◆ Press key [FSW] to switch LCD Into clock display.
- ◆ Press key [HR] adjust 'h' and if pressed more than 2 seconds, it will be adjusted quickly.
- ◆ Press key [MN] to adjust 'm' and if pressed more than 2 seconds, it will be adjusted quickly.

power On/Off

- ◆ Press [FSW] 4 seconds to turn off the machine, but the clock continue working.
- ◆ Press key [FSW] to turn on the machine.